

SCOPE OF STANDARD FURNACES FOR HEAT TREATMENT 2016

<i>Batch bogie hearth furnaces gas heated</i> ТермоГаз® [ThermoGas] series
ТермоГаз® – ДО -11.15.10/1100
ТермоГаз® – ДО -13.25.15/1000
ТермоГаз® – ДО -16.32.12/1200
ТермоГаз® – ДО -15.35.15/1100
ТермоГаз® – ДО -15.75.15/1100
ТермоГаз® – ДО - 20.30.10/1000
ТермоГаз® – ДО - 20.30.10/1300
ТермоГаз® – ДО - 20.45.15/1100
ТермоГаз® – ДО - 20.65.15/1100
ТермоГаз® – ДО - 25.40.17/1000
ТермоГаз® – ДО - 25.60.18/1000
Термогаз® – ДО - 30.30.11/900
ТермоГаз® – ДО - 30.50.15/1100
ТермоГаз® – ДО - 30.60.15/1150
ТермоГаз® – ДО - 30.70.20/1100
ТермоГаз® – ДО - 30.75.20/1100
ТермоГаз® – ДО - 30.110.20/850
ТермоГаз® – ДО - 35.75.25/1100
ТермоГаз® - ДО-35.80.22/1100
ТермоГаз® - ДО-35.100.27/1200
ТермоГаз® - ДО-35.120.25/1150
ТермоГаз® - ДО-40.65.35/1150
ТермоГаз® - ДО-40.70.35/500
ТермоГаз® - ДО-40.100.20/1100
ТермоГаз® - ДО-40.150.40/1100

<i>Batch bogie hearth furnaces electrically heated</i> ТермоМастер® [ThermoMaster] series
ТермоМастер® - ДО-8,1.16. 8,5/1100/750
ТермоМастер® - ДО-14.16.8/1100/750
ТермоМастер® - ДО-10-20-10/1100/750
ТермоМастер® - ДО-10-30-10/1100/750
ТермоМастер® - ДО- 11.35.10/1100/750
ТермоМастер® - ДО- 13.20.15/1100/750
ТермоМастер® - ДО-15.15.15/1100
ТермоМастер® - ДО-15-20-10/1100/750
ТермоМастер® - ДО-15-20-15/1100/750
ТермоМастер® - ДО-15.30.10/1100/750
ТермоМастер® - ДО-17.42.20/1100/750
ТермоМастер® - ДО- 20.20.11,5/1100/750
ТермоМастер® - ДО- 20.30.14,5/1100/750
ТермоМастер® - ДО- 20.38.7,5/1100/750
ТермоМастер® - ДО-20.40.18/1100/750
ТермоМастер® - ДО-20.60.18/1100/750
ТермоМастер® - ДО-23.43.11,5/1100/750
ТермоМастер® - ДО-25.40.20/1100/750
ТермоМастер® - ДО-11.35.17/1100/750

Batch furnaces with stationary hearth gas heated (forging furnaces) ТермоГаз® [ThermoGas] series
ТермоГаз® - HO-8.15.6/1300
ТермоГаз® - HO-9.10.5/1300
ТермоГаз® - HO-13.13.6/1300
ТермоГаз® - HO-20.20.8/1300
ТермоГаз® - 2HO-8.15.6/1300
ТермоГаз® - 2HO-9.18.8/1300

Batch furnaces with stationary hearth electrically heated ТермоМастер® [ThermoMaster] series
ТермоМастер® - HO-3.6.2/1100
ТермоМастер® - HO-5.8.3/1100
ТермоМастер® - HO-5.8.3/750
ТермоМастер® - HO-6.12.4/1100
ТермоМастер® - HO-6.12.4/750
ТермоМастер® - HO-8.14.5/1100
ТермоМастер® - HO-8.14.5/750

Shaft-type furnaces electrically heated ТермоМастер® [ThermoMaster] series
ТермоМастер® - ШО-6.12/1100
ТермоМастер® - ШО-6.12/750
ТермоМастер® - ШО-6.20/750
ТермоМастер® - ШО-6.20/1100
ТермоМастер® - ШО- 6.30/1100
ТермоМастер® - ШО- 6.40/1100
ТермоМастер® - ШО- 9,5.13/1100
ТермоМастер® - ШО- 9,5.13/750
ТермоМастер® - ШО- 12.18/1100
ТермоМастер® - ШО- 12.18/750
ТермоМастер® - ШО- 12.32/1100
ТермоМастер® - ШО- 12.40/1100
ТермоМастер® - ШО- 12.50/1100
ТермоМастер® - ШО- 12.10/1100
ТермоМастер® - ШО- 12.10/750
ТермоМастер® - ШО- 14.10/1100
ТермоМастер® - ШО- 14.10/750
ТермоМастер® - ШО- 14.20/1100

All salient features of application and Customer wish as to the equipment or options are discussed at Order opening. Contact our experts for additional advisory support.

**84105, Ukraine, Donetsk region,
Slavyansk, Sverdlov str., 1A
tel.(+3806262) 35488, (+38062) 667338
commerce@ikm.donbass.com
www.keramash.ua**

**ТермоМастер®
ТермоГаз®**